

Work Order ID 96950

Tuesday, February 12, 2013

Page 1

Item ID:

Revision ID:

Item Name:

Draw Nbr:

Revision Nbr

Reference: ADD DSI 12-692

Description: ADD DSI TO KITS IN STOCK: D355-600-143 X 1 B#21558, D350-600-241 X 2 B#64741 X 1 AND B#70175 X 1 - 98651
PER ECN 12-692

98652
Start Date: 2/12/2013 1:3

Required Date: 2/13/2013

Cust Item ID:

98650
Start Qty: 1.0000

Reqd Qty: 1.0000

Customer ID:

Sales Order:

Approvals:

Process Plan:

Date:

Tooling:

Date:

QC:

Date:

SPC (Y/N):

Date:

Hours

See w/o's 98650, 98651, 98652

MF
12-3-13